With RoofGuard on duty 24/7, protected roof drains should **only require an annual inspection and cleaning** to remove accumulated seasonal debris.

**DEBRIS FLOATS ABOVE** 



WATER FLOWS BELOW



۲

In applications where a cast iron RoofGuard is preferred, MIFAB's model RG2016DDC cast iron RoofGuard is ideal!



Download our full RoofGuard catalog to your mobile device.



MIFAB<sup>®</sup>. Inc. 1321 West 119th St, Chicago, IL 60643-5109 Toll Free 1-800-465-2736, Fax 1-773-341-3049 Canada Toll Free: 1-800-387-3880 www.mifab.com sales@mifab.com

View video: www.Roof-Guard.net

LIT-058TF

( )

MAKE ROOF & SCUPPER DRAINS UNCLOGGABLE

**MIFAB** 

Roof Guard


## WHY RoofGuard?

#### RoofGuard ELIMINATES STANDING WATER

• Patented design increases surface area by 5x or more making a RoofGuard protected drain virtually uncloggable

#### **RoofGuard SAVES \$\$**

• RoofGuard works 24/7 reducing drain cleaning/maintenance from year round to an annual inspection.



• Eliminates leaks and costly repairs caused by clogged drains.

۲

#### RoofGuard IS SIMPLE TO USE

- RoofGuard will replace any Roof Drain Dome up to 15" and Scupper Drains 6" - 12" wide.
- Installation is fast, simple, and requires no tools.
- Removable Top allows easy access to drain and piping without detaching RoofGuard.

### **INSTALL IT**

**1.** Clean and remove all dirt, debris, and other loose material in area around the drain where RoofGuard is to be installed. After cleaning, if the area is wet, dry it off removing as much moisture as possible.

- **2.** Remove and dispose of current drain dome or scupper cover.
- **3.** Turn RoofGuard over and fill the Attachment Pods with an exterior rated adhesive. Make sure the Pods are completely full and over flowing with adhesive to properly bond.
- **4.** Turn RoofGuard over. Install over the drain. Press firmly on top of the Attachment Pods to ensure good adhesion to the roof surface.


#### **FORGET IT!**



# THIS YEAR INSTALL IT AND FORGET IT







۲